


(PART #221700)



ITEM NO.	PART#	DESCRIPTION
1	221718	GEAR BOX_HOUSING
2	221716	RETAINING RING, BEARING SMALL
3	221717	RETAINING RING, BEARING, LARGE
4	2217051	PIPE_NOZZLE HEAD
5	221714	BEARING,LARGE, TWISTER
6	221713	BEARING,SMALL, TWISTER
7	221703	AIR MOTOR
8	221702	AIR MOTOR_HOUSING
9	221701	STEEL PIPE_AIR MOTOR
10	221710	LINER, INT, NYLON
11	221706	ABRASIVE TUBE
12	221705	NOZZLE HEAD
13	31075	NOZZLE_5/16"
-	31074	NOZZLE 1/4"
-	31076	NOZZLE 3/8"
16	221729	BRACKET B
17	221728	BRACKET A
18	221707	HOSE ADAPTOR W/GASKET
19	221709	GASKET_HOSE ADAPTOR
20	221711	GASKET_NOZZLE
22	221704	GEAR
23	221712	DUST SEAL, FELT
24	221715	Abrasive seal, RUBBER
25	221708	CARRIAGE WHEEL ONLY, RUBBER

221720 LEG & WHEELS KIT, SMALL
 221725 LEG & WHEELS KIT, LARGE